


2 HP Dust Collector



Parts List

Parts Explosion



Parts List

Key No.	Description	Key No.	Description
1	Caster	21	Screw
3	Base plate	22	Impeller
4	Flat washer	23	Cap head nut
5	Motor base	24	Inlet
6	Hex bolt	25	Fan housing cover
7	Motor cable	26	Screw
8	Motor	27	Flat washer
9	Switch body	28	Hex bolt
10	Center key	29	Rubber gasket
13	Upper bag support	30	5" Outlet
14	Collector support	31	Hose clamp
15	Hex bolt	32	5" Hose
16	Hex nut	33	Collector
17	Key	34	Strap
18	Fan washer	35	Filter bag
20	Flat washer	36	Dust bag
		37	Fan housing